



# UAF\_STANDARD

UAF PLOT SETTINGS:  
 FOR LINEWEIGHTS FILE.  
 USE UNCHECK "SCALE LINEWEIGHTS" SETTING IN PLOT DIALOG BOX  
 FOR FULL SIZE PLOTS.  
 USE TRUE TYPE COLORS FOR COLOR TO SHOW ON FINAL PLOTS.  
 .CTB FILE LOCATED AT: T:\AutoCAD\DDCStandard\Plot Styles